

List of Compatible Projector Models

Wireless Manager ME6.0

Wireless Manager mobile edition 6.0

- As of July 2012 -

■ In using this software, bear in mind that the items whose settings must be selected for the projectors and the functions that can be used may differ from one projector model to another. While referring to the table below, check out that projector models are compatible with the software before using them.

List of latest projector models

[PT-VX505N / PT-VW435N] 2

List of projector models

PT-DW530	3
PT-DX500	3
PT-DZ570	3
PT-F300	5
PT-F300NT	5
PT-FW300	5
PT-FW300NT	5
PT-FW430	3
PT-FX400	3
PT-LB75NT	6
PT-LB80NT	6
PT-LB90NT	6
PT-LW80NT	6
PT-VW435N	2
PT-VX400NT	4
PT-VX505N	2

PT-VX505N / PT-VW435N

Alphabet letters are omitted from the end of the above product numbers because the specifications are common regardless of whether the alphabet letters are included.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

○: Possible ×: Not possible

Function		Compatibility
Connection method/Control	[S-Direct] connection/[M-Direct] connection	○
	[S-MAP] connection	○
	[1-4/U] connection	○
	[IP designation] connection	○
	[USB display] connection	○ *3
Projection method	Live mode *1	○
	Multi-Live mode *2	○
	Multiple unit live mode *2	×
	Multiple unit Multi-Live mode *2	×

*1: PC audio can only be output from the projector in "Live mode".
However, it is necessary to install this software (driver) on the PC.

*2: Audio cannot be output in "Multi-Live mode"/"Multiple unit live mode"/"Multiple unit Multi-Live mode".

*3: A USB cable is required for this connection.

Limitations of use with software not installed

- Function that outputs audio together with images in Live Mode cannot be used.

■ PT-DZ570 / PT-DW530 / PT-DX500

■ PT-FW430 / PT-FX400

A wireless module, purchased separately, is required when connecting any of the above models using a wireless LAN.

It is not required when connecting one of the above models using a wired LAN.

Furthermore, alphabet letters are omitted from the end of the above product numbers because the specifications are common regardless of whether the alphabet letters are included.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

○: Possible ×: Not possible

Function		Compatibility
Connection method/Control	[S-Direct] connection/[M-Direct] connection	×
	[S-MAP] connection	○
	[1-4/U] connection	○
	[IP designation] connection	○
	[USB display] connection	×
Projection method	Live mode *1	○
	Multi-Live mode *2	○
	Multiple unit live mode *2	×
	Multiple unit Multi-Live mode *2	×

*1: PC audio can only be output from the projector in "Live mode".
However, it is necessary to install this software (driver) on the PC.

*2: Audio cannot be output in "Multi-Live mode"/"Multiple unit live mode"/"Multiple unit Multi-Live mode".

Limitations of use with software not installed

- Function that outputs audio together with images in Live Mode cannot be used.

PT-VX400NT

Alphabet letters are omitted from the end of the above product numbers because the specifications are common regardless of whether the alphabet letters are included.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

○: Possible ×: Not possible

Function		Compatibility
Connection method/Control	[S-Direct] connection/[M-Direct] connection	×
	[S-MAP] connection	○
	[1-4/U] connection	○
	[IP designation] connection	○
	[USB display] connection	○
Projection method	Live mode *1	○
	Multi-Live mode *2	○
	Multiple unit live mode *2	×
	Multiple unit Multi-Live mode *2	×

*1: PC audio can only be output from the projector in "Live mode".
However, it is necessary to install this software (driver) on the PC.

*2: Audio cannot be output in "Multi-Live mode"/"Multiple unit live mode"/"Multiple unit Multi-Live mode".

Limitations of use with software not installed

- Function that outputs audio together with images in Live Mode cannot be used.

■ PT-FW300NT / PT-FW300 / PT-F300NT / PT-F300

Alphabet letters are omitted from the end of the above product numbers because the specifications are common regardless of whether the alphabet letters are included.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

○: Possible ×: Not possible

Function		Compatibility
Connection method/Control	[S-Direct] connection/[M-Direct] connection	×
	[S-MAP] connection	○ *3
	[1-4/U] connection	○ *4
	[IP designation] connection	○
	[USB display] connection	×
Projection method	Live mode *1	○
	Multi-Live mode *2	○
	Multiple unit live mode *2	×
	Multiple unit Multi-Live mode *2	×

*1: PC audio can only be output from the projector in "Live mode".
However, it is necessary to install this software (driver) on the PC.

*2: Audio cannot be output in "Multi-Live mode"/"Multiple unit live mode"/"Multiple unit Multi-Live mode".

*3: This connection cannot be used for the PT-FW300 and PT-F300 because these models do not support a wireless LAN.

*4: When using a wired LAN connection with the PT-FW300 and PT-F300, only use by [U (user)] is possible.

Limitations of use with software not installed

- Function that outputs audio together with images in Live Mode cannot be used.

■ PT-LB90NT / PT-LW80NT / PT-LB80NT / PT-LB75NT

Alphabet letters are omitted from the end of the above product numbers because the specifications are common regardless of whether the alphabet letters are included.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

○: Possible ×: Not possible

Function		Compatibility
Connection method/Control	[S-Direct] connection/[M-Direct] connection	×
	[S-MAP] connection	○
	[1-4/U] connection	○
	[IP designation] connection	○
	[USB display] connection	×
Projection method	Live mode *1	○
	Multi-Live mode *2	○
	Multiple unit live mode *2	×
	Multiple unit Multi-Live mode *2	×

*1: PC audio can only be output from the projector in "Live mode".
However, it is necessary to install this software (driver) on the PC.

*2: Audio cannot be output in "Multi-Live mode"/"Multiple unit live mode"/"Multiple unit Multi-Live mode".

Limitations of use with software not installed

- Function that outputs audio together with images in Live Mode cannot be used.